

Wizard DMX Protocol

1

B/O	closed	DIMMER	open	fast	STROBE	B/O	STAND-ALONE	music	auto	B/O	225	250
-----	--------	--------	------	------	--------	-----	-------------	-------	------	-----	-----	-----

2

slow	PARABOLIC REFLECTOR	fast	stop	fast	CW rotation	slow	250
------	---------------------	------	------	------	-------------	------	-----

3

0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	Color wheel rotation (slow - fast)	No rot	Twinkle rotation	No Stand rot. alone	250
---	---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	------------------------------------	--------	------------------	---------------------	-----

4

0	1	2	3	4	5	6	7	8	9	10	11	12	13	Gobo wheel rotation (slow - fast)	Gobo wheel rotation (slow - fast)	No Stand rot. alone	250
---	---	---	---	---	---	---	---	---	---	----	----	----	----	-----------------------------------	-----------------------------------	---------------------	-----

5

left	MIRROR DRUM SWIVEL	right	250
------	--------------------	-------	-----

6

slow	MIRROR DRUM ROTATION	fast	stop	fast	CW rotation	slow	250
------	----------------------	------	------	------	-------------	------	-----

7

fast	MIRROR DRUM SWIVEL SPEED (ONLY IN 8-CHANNEL MODE)	slow	250
------	---	------	-----

8

fast	COLOR/GOBO SPEED (ONLY IN 8-CHANNEL MODE)	slow	250
------	---	------	-----

Wizard 1-Channel DMX Mode

B/O	LIGHT ON	STROBE	slow	medium	fast	MUSIC TRIGGER	random	MANUAL TRIGGER	← →	250
-----	----------	--------	------	--------	------	---------------	--------	----------------	-------	-----