

## Mac250 Wash - Service schedule - Level 1

	Part description	Part number	Total lamp hours																								NOTE
			750 hrs	1500 hrs	2250 hrs	3000 hrs	3750 hrs	4500 hrs	5250 hrs	6000 hrs	6750 hrs	7500 hrs	8250 hrs	9000 hrs	9750 hrs	10500 hrs	11250 hrs	12000 hrs	12750 hrs	13500 hrs	14250 hrs	15000 hrs	15750 hrs	16500 hrs	17250 hrs	18000 hrs	
F I X T U R E  H E A D	<b>Head - general</b>		C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	After removing the modules, clean head thoroughly with compressed air to remove all dust and dirt
	Fans	62222042	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	Clean fan for dust and dirt. Check that it can turn freely without making any strange sounds.
	Airfilters	20800140	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	
	Front lens		C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	
	<b>Effect module</b>		C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	Clean module thoroughly with compressed air to remove all dust
B A S E	<b>Base - general</b>		C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	After removing the covers, clean base thoroughly with compressed air to remove all dust
	<b>Display module</b>		C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	After removing the module, clean it thoroughly with compressed air to remove all dust
<b>Technician skill level</b> →			Level 1	Level 1	Level 1	Level 1	Level 1	Level 1	Level 1	Level 1	Level 1	Level 1	Level 1	Level 1	Level 1	Level 1	Level 1	Level 1	Level 1	Level 1	Level 1	Level 1	Level 1	Level 1	Level 1	Level 1	

Conditions	
Ambient temperature	40° C
Voltage / frequency	Nominel +/- 10%

Code	
I	Inspect
R	Replace
C	Clean
L	Lubricate
A	Adjust
U	Update